

Billet Seat Latch

Can-Am Renegade 2012 +



Kit includes

1x Billet Aluminum Latch

Tools needed

Slotted Screwdriver

Installation

1. Remove the seat and turn over to access the stock plastic latch.
2. Insert a slotted screwdriver between the factory latch and seat tab, you will pry toward the latch (moving the seat pan hole away from the latch)



3. While prying on with the screwdriver twisting and pulling on the factory plastic latch to remove the tab/pin on the side you are prying on from the seat pan hole.

4. Once you have one side out you can continue to twist and pull to remove the factory latch (will not be reusing this)
5. To install the new latch in the same direction as the old latch. Install one pin first on the latch then push firmly down to pop other pin into the seat pan.



6. To install the seat back on the atv you will need to hold the latch in and push firmly down on the seat till it latches.
7. Remove the seat by pushing down on the seat and pulling in the latch firmly (this will require more force then the stock latch to remove)



8. Installation video on website
<http://www.bnrmotorsports.com/forms-and-info/instructions.html>